


Foiese 105, 203, and 205 A/V Instructions

The A/V control panel is located on the east (interior) wall.

1. To initiate the system, touch the main splash screen.



To send 1 device to ALL screens:



From the panel, select the input device you want everyone to see.

There are 4 wireless "Pods" and 1 wall panel in the room. If 203 and 205 are combined, there are 6 "Pods" and 2 wall panels. HDMI and VGA cables for connecting to the wall panel can be borrowed from the FIS Info Desk.

Whichever you select will appear on **all** exterior screens.

To send each device to separate screens:




Select the **Default Layout** button to send each "Pod" to each projector.

In this scenario, Pod A will display on the room A projector, Pod B will display on the B projector, etc.

Additional Room Controls



To control each screen individually, press the gear button. Up/down and Image Mute are found here. *Whiteboard Access* mode mutes the projector and sends the screen up.



To adjust **Lighting** or **Window Shades** press the corresponding button.



To **shut down** the system, press the power button.